

XanLite®

DIM-K



SG50SDS

Choose your intensity!

Installer les ampoules DIM-K.

Install the DIM-K bulb.

Installate le lampadibe DIM-K.

Instalar las bombillas DIM-K.

Installieren sie die DIM-K birne.

1



2



2- Réglage de l'intensité de lumière / Choose the intensity of light / Regulación de la intensidad de luz / Verordening van de intensiteit van het licht / Regulamento da intensidade de luz

- ⌚ Effectuer une commutation pour passer d'une intensité à l'autre.
- ⌚ Make a switch to pass from an intensity to the other one.
- ⌚ Effettuare una commutazione per passare di un'intensità all'altro.
- ⌚ Efectuar una commutación para pasar de una intensidad a la otra.
- ⌚ Einde Vertauschung ausführen, um von einer intensität zu anderer zu gehen.

SWITCH



100%
clic x1



100%
2700K

50%
clic x2



50%
2700K

10%
clic x3



10%
2700K

XanLite - Yantec
45 avenue Victor Hugo
93300 Aubervilliers - France
www.xanlite.com
notice version 1.0